

## CHAPTER FOUR ORGANIC ANALYTES

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in this chapter is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

### 4.1 SAMPLING CONSIDERATIONS

#### 4.1.1 Introduction

Following the initial and critical step of designing a sampling plan (Chapter Nine) is the implementation of that plan such that a representative sample of the solid waste is collected. Once the sample has been collected it must be stored and preserved to maintain the chemical and physical properties that it possessed at the time of collection. The sample type, type of containers and their preparation, possible forms of contamination, and preservation methods are all items which must be thoroughly examined in order to maintain the integrity of the samples. This section highlights considerations which must be addressed in order to maintain a sample's integrity and representativeness. This section is, however, applicable only to trace analyses.

Quality Control (QC) requirements need not be met for all compounds presented in the Table of Analytes for the method in use, rather, they must be met for all compounds reported. A report of non-detect is considered a quantitative report, and must meet all applicable QC requirements for that compound and the method used.

#### 4.1.2 Sample Handling and Preservation

This section deals separately with volatile and semivolatile organics. Refer to Chapter Two and Table 4-1 of this section for sample containers, sample preservation, and sample holding time information.

##### Volatile Organics

Standard 40 mL glass screw-cap VOA vials with Teflon lined silicone septa may be used for liquid matrices. Special 40 mL VOA vials for purge-and-trap of solid samples are described in Method 5035. VOA vials for headspace analysis of solid samples are described in Method 5021. Standard 125 mL widemouth glass containers may be used for Methods 5031 and 5032. However, the sampling procedures described in Method 5035 may minimize sample preparation analyte loss better than the procedures described in Methods 5031 and 5032. The vials and septa should be washed with soap and water and rinsed with distilled deionized water. After thoroughly cleaning the vials and septa, they should be placed in an oven and dried at 100°C for approximately one hour.

**NOTE:** Do not heat the septa for extended periods of time (i.e., more than one hour, because the silicone begins to slowly degrade at 105°C).

When collecting the samples, liquids and solids should be introduced into the vials gently to reduce agitation which might drive off volatile compounds.

In general, liquid samples should be poured into the vial without introducing any air bubbles within the vial as it is being filled. Should bubbling occur as a result of violent pouring, the sample must be poured out and the vial refilled. The vials should be completely filled at the time of sampling, so that when the septum cap is fitted and sealed, and the vial inverted, no headspace is visible. The sample should be hermetically sealed in the vial at the time of sampling, and must not be opened prior to analysis to preserve their integrity.

- Due to differing solubility and diffusion properties of gases in LIQUID matrices at different temperatures, it is possible for the sample to generate some headspace during storage. This headspace will appear in the form of micro bubbles, and should not invalidate a sample for volatiles analysis.
- The presence of a macro bubble in a sample vial generally indicates either improper sampling technique or a source of gas evolution within the sample. The latter case is usually accompanied by a buildup of pressure within the vial, (e.g. carbonate-containing samples preserved with acid). Studies conducted by the USEPA (EMSL-Ci, unpublished data) indicate that "pea-sized" bubbles (i.e., bubbles not exceeding 1/4 inch or 6 mm in diameter) did not adversely affect volatiles data. These bubbles were generally encountered in wastewater samples, which are more susceptible to variations in gas solubility than are groundwater samples.

Immediately prior to analysis of liquid samples, the aliquot to be analyzed should be taken from the vial using the instructions from the appropriate sample introduction technique:

- For smaller analysis volumes, a gas-tight syringe may be inserted directly through the septum of the vial to withdraw the sample.
- For larger analysis volumes, (e.g. purge-and-trap analyses) the sample may be carefully poured into the syringe barrel. Opening a volatile sample to pour a sample into a syringe destroys the validity of the sample for future analysis. Therefore, if there is only one VOA vial, it is strongly recommended that the analyst fill a second syringe at this time to protect against possible loss of sample integrity. This second sample is maintained only until such time as the analyst has determined that the first sample has been analyzed properly.

If these guidelines are not followed, the validity of the data generated from the samples may be suspect.

VOA vials for samples with solid or semi-solid matrices (e.g., sludges) should be filled according to the guidance given in the appropriate 5000 series sample introduction method (see Table 4-1) to be used. When 125-mL widemouth glass containers are used, the containers should be filled as completely as possible. The 125-mL vials should be tapped slightly as they are filled to try and eliminate as much free air space as possible. A minimum of two vials should also be filled per sample location.

At least two VOA vials should be filled and labeled immediately at the point at which the sample is collected. They should NOT be filled near a running motor or any type of exhaust system because discharged fumes and vapors may contaminate the samples. The two vials from each sampling location should then be sealed in separate plastic bags to prevent cross-contamination between samples, particularly if the sampled waste is suspected of containing high levels of volatile organics. (Activated carbon may also be included in the bags to prevent cross-contamination from highly contaminated samples). VOA samples may also be contaminated by diffusion of volatile

organics through the septum during shipment and storage. To monitor possible contamination, a trip blank prepared from organic-free reagent water (as defined in Chapter One) should be carried throughout the sampling, storage, and shipping process.

#### Semivolatile Organics (including Pesticides, PCBs and Herbicides.)

Containers used to collect samples for the determination of semivolatile organic compounds should be soap and water washed followed by methanol (or isopropanol) rinsing (see Sec. 4.1.4 for specific instructions on glassware cleaning). The sample containers should be of glass or Teflon, and have screw-caps with Teflon lined septa. In situations where Teflon is not available, solvent-rinsed aluminum foil may be used as a liner. However, acidic or basic samples may react with the aluminum foil, causing eventual contamination of the sample. Plastic containers or lids may NOT be used for the storage of samples due to the possibility of sample contamination from the phthalate esters and other hydrocarbons within the plastic. Sample containers should be filled with care so as to prevent any portion of the collected sample coming in contact with the sampler's gloves, thus causing contamination. Samples should not be collected or stored in the presence of exhaust fumes. If the sample comes in contact with the sampler (e.g. if an automatic sampler is used), run organic-free reagent water through the sampler and use as a field blank.

#### 4.1.3 Safety

Safety should always be the primary consideration in the collection of samples. A thorough understanding of the waste production process, as well as all of the potential hazards making up the waste, should be investigated whenever possible. The site should be visually evaluated just prior to sampling to determine additional safety measures. Minimum protection of gloves and safety glasses should be worn to prevent sample contact with the skin and eyes. A respirator should be worn even when working outdoors if organic vapors are present. More hazardous sampling missions may require the use of supplied air and special clothing.

#### 4.1.4 Cleaning of Glassware

In the analysis of samples containing components in the parts per billion range, the preparation of scrupulously clean glassware is necessary. Failure to do so can lead to a myriad of problems in the interpretation of the final chromatograms due to the presence of extraneous peaks resulting from contamination. Particular care must be taken with glassware such as Soxhlet extractors, Kuderna-Danish evaporative concentrators, sampling-train components, or any other glassware coming in contact with an extract that will be evaporated to a smaller volume. The process of concentrating the compounds of interest in this operation may similarly concentrate the contaminating substance(s), which may seriously distort the results.

The basic cleaning steps are:

1. Removal of surface residuals immediately after use;
2. Hot soak to loosen and float most particulate material;
3. Hot water rinse to flush away floated particulates;
4. Soak with an oxidizing agent to destroy traces of organic compounds;
5. Hot water rinse to flush away materials loosened by the deep penetrant soak;

6. Distilled water rinse to remove metallic deposits from the tap water;
7. Alcohol, e.g., isopropanol or methanol, rinse to flush off any final traces of organic materials and remove the water; and
8. Flushing the item immediately before use with some of the same solvent that will be used in the analysis.

Each of these eight fundamental steps are discussed here in the order in which they appeared on the preceding page.

1. As soon possible after glassware (i.e., beakers, pipets, flasks, or bottles) has come in contact with sample or standards, the glassware should be flushed with alcohol before it is placed in the hot detergent soak. If this is not done, the soak bath may serve to contaminate all other glassware placed therein.
2. The hot soak consists of a bath of a suitable detergent in water of 50°C or higher. The detergent, powder or liquid, should be entirely synthetic and not a fatty acid base. There are very few areas of the country where the water hardness is sufficiently low to avoid the formation of some hard-water scum resulting from the reaction between calcium and magnesium salts with a fatty acid soap. This hard-water scum or curd would have an affinity particularly for many chlorinated compounds and, being almost wholly water-insoluble, would deposit on all glassware in the bath in a thin film.

There are many suitable detergents on the wholesale and retail market. Most of the common liquid dishwashing detergents sold at retail are satisfactory but are more expensive than other comparable products sold industrially. Alconox, in powder or tablet form, is manufactured by Alconox, Inc., New York, and is marketed by a number of laboratory supply firms. Sparkleen, another powdered product, is distributed by Fisher Scientific Company.

3. No comments required.
4. The most common and highly effective oxidizing agent for removal of traces of organic compounds is the traditional chromic acid solution made up of concentrated sulfuric acid and potassium or sodium dichromate. For maximum efficiency, the soak solution should be hot (40-50°C). Safety precautions must be rigidly observed in the handling of this solution. Prescribed safety gear should include safety goggles, rubber gloves, and apron. The bench area where this operation is conducted should be covered with fluorocarbon sheeting because spattering will disintegrate any unprotected surfaces.

The potential hazards of using chromic-sulfuric acid mixture are great and have been well publicized. There are now commercially available substitutes that possess the advantage of safety in handling. These are biodegradable concentrates with a claimed cleaning strength equal to the chromic acid solution. They are alkaline, equivalent to ca. 0.1 N NaOH upon dilution, and are claimed to remove dried blood, silicone greases, distillation residues, insoluble organic residues, etc. They are further claimed to remove radioactive traces and will not attack glass or exert a corrosive effect on skin or clothing. One such product is "Chem Solv 2157," manufactured by Mallinckrodt and available through laboratory supply firms. Another comparable product is "Detex," a product of Borer-Chemie, Solothurn, Switzerland.

5, 6, and 7. No comments required.

8. There is always a possibility that between the time of washing and the next use, the glassware could pick up some contamination from either the air or direct contact. To ensure against this, it is good practice to flush the item immediately before use with some of the same solvent that will be used in the analysis.

The drying and storage of the cleaned glassware is of critical importance to prevent the beneficial effects of the scrupulous cleaning from being nullified. Pegboard drying is not recommended. It is recommended that laboratory glassware and equipment be dried at 100°C. Under no circumstances should such small items be left in the open without protective covering. The dust cloud raised by the daily sweeping of the laboratory floor can most effectively recontaminate the clean glassware.

As an alternate to solvent rinsing, the glassware can be heated to a minimum of 300°C to vaporize any organics. Do not use this high temperature treatment on volumetric glassware, glassware with ground glass joints, or sintered glassware.

#### 4.1.5 High Concentration Samples

Cross contamination of trace concentration samples may occur when prepared in the same laboratory with high concentration samples. Ideally, if both type samples are being handled, a laboratory and glassware dedicated solely to the preparation of high concentration samples would be available for this purpose. If this is not feasible, as a minimum when preparing high concentration samples, disposable glassware should be used or, at least, glassware dedicated entirely to the high concentration samples. Avoid cleaning glassware used for both trace and high concentration samples in the same area.

TABLE 4-1.  
SAMPLE CONTAINERS, PRESERVATION, TECHNIQUES, AND HOLDING TIMES

VOLATILE ORGANICS			
Sample Matrix	Container	Preservative	Holding Time
Concentrated Waste Samples	Method 5035: 40-mL vials with stirring bar. Method 5021: See method. Methods 5031 & 5032: 125-mL widemouth glass container. Use Teflon-lined lids for all procedures.	Cool to 4°C.	14 days
Aqueous Samples With No Residual Chlorine Present	Methods 5030, 5031, & 5032: 2 X 40-mL vials with Teflon-lined septum caps	Cool to 4°C and adjust pH to less than 2 with H <sub>2</sub> SO <sub>4</sub> , HCl, or solid NaHSO <sub>4</sub> .	14 days
Aqueous Samples WITH Residual Chlorine Present	Methods 5030, 5031, & 5032: 2 X 40-mL vials with Teflon-lined septum caps	Collect sample in a 125-mL container which has been pre-preserved with 4 drops of 10% sodium thiosulfate solution. Gently swirl to mix sample and transfer to a 40-mL VOA vial. Cool to 4°C and adjust pH to less than 2 with H <sub>2</sub> SO <sub>4</sub> , HCl, or solid NaHSO <sub>4</sub> .	14 days
Acrolein and Acrylonitrile in Aqueous Sample	Methods 5030, 5031, & 5032: 2 X 40-mL vials with Teflon-lined septum caps	Adjust to pH 4-5. Cool to 4°C.	14 days
Solid Samples (e.g. soils, sediments, sludges, ash)	Method 5035: 40-mL vials with septum and stirring bar. Method 5021: See method. Methods 5031 & 5032: 125-mL widemouth glass container with Teflon-lined lids.	See the individual methods.	14 days

SEMIVOLATILE ORGANICS/ORGANOCHLORINE PESTICIDES/PCBs AND HERBICIDES			
Sample Matrix	Container	Preservative	Holding Time
Concentrated Waste Samples	125-mL widemouth glass with Teflon-lined lid	None	Samples extracted within 14 days and extracts analyzed within 40 days following extraction.
Aqueous Samples With No Residual Chlorine Present	1-gal., 2 x 0.5-gal., or 4 x 1-L amber glass container with Teflon-lined lid	Cool to 4°C	Samples extracted within 7 days and extracts analyzed within 40 days following extraction.
Aqueous Samples WITH Residual Chlorine Present	1-gal., 2 x 0.5-gal., or 4 x 1-L, amber glass container with Teflon-lined lid.	Add 3-mL 10% sodium thiosulfate solution per gallon (or 0.008%). Addition of sodium thiosulfate solution to sample container may be performed in the laboratory prior to field use. Cool to 4°C.	Samples extracted within 7 days and extracts analyzed within 40 days following extraction.
Solid Samples (e.g. soils, sediments, sludges, ash)	250-mL widemouth glass container with Teflon-lined lid	Cool to 4°C	Samples extracted within 14 days and extracts analyzed within 40 days following extraction.

## 4.2 SAMPLE PREPARATION METHODS

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

### 4.2.1 EXTRACTIONS AND PREPARATIONS

The following methods are included in this section:

<b>Method 3500B:</b>	Organic Extraction and Sample Preparation
<b>Method 3510C:</b>	Separatory Funnel Liquid-Liquid Extraction
<b>Method 3520C:</b>	Continuous Liquid-Liquid Extraction
<b>Method 3535:</b>	Solid-Phase Extraction (SPE)
<b>Method 3540C:</b>	Soxhlet Extraction
<b>Method 3541:</b>	Automated Soxhlet Extraction
<b>Method 3542:</b>	Extraction of Semivolatile Analytes Collected Using Method 0010 (Modified Method 5 Sampling Train)
<b>Method 3545:</b>	Pressurized Fluid Extraction (PFE)
<b>Method 3550B:</b>	Ultrasonic Extraction
<b>Method 3560:</b>	Supercritical Fluid Extraction of Total Recoverable Petroleum Hydrocarbons
<b>Method 3561:</b>	Supercritical Fluid Extraction of Polynuclear Aromatic Hydrocarbons
<b>Method 3580A:</b>	Waste Dilution
<b>Method 3585:</b>	Waste Dilution for Volatile Organics
<b>Method 5000:</b>	Sample Preparation for Volatile Organic Compounds
<b>Method 5021:</b>	Volatile Organic Compounds in Soils and Other Solid Matrices Using Equilibrium Headspace Analysis
<b>Method 5030B:</b>	Purge-and-Trap for Aqueous Samples
<b>Method 5031:</b>	Volatile, Nonpurgeable, Water-Soluble Compounds by Azeotropic Distillation
<b>Method 5032:</b>	Volatile Organic Compounds by Vacuum Distillation
<b>Method 5035:</b>	Closed-System Purge-and-Trap and Extraction for Volatile Organics in Soil and Waste Samples
<b>Method 5041A:</b>	Analysis for Desorption of Sorbent Cartridges from Volatile Organic Sampling Train (VOST)



## 4.2 SAMPLE PREPARATION METHODS

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

### 4.2.2 CLEANUP

The following methods are included in this section:

<b>Method 3600C:</b>	Cleanup
<b>Method 3610B:</b>	Alumina Cleanup
<b>Method 3611B:</b>	Alumina Column Cleanup and Separation of Petroleum Wastes
<b>Method 3620B:</b>	Florisil Cleanup
<b>Method 3630C:</b>	Silica Gel Cleanup
<b>Method 3640A:</b>	Gel-Permeation Cleanup
<b>Method 3650B:</b>	Acid-Base Partition Cleanup
<b>Method 3660B:</b>	Sulfur Cleanup
<b>Method 3665A:</b>	Sulfuric Acid/Permanganate Cleanup

### 4.3 DETERMINATION OF ORGANIC ANALYTES

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

#### 4.3.1 GAS CHROMATOGRAPHIC METHODS

The following methods are included in this section:

<b>Method 8000B:</b>	Determinative Chromatographic Separations
<b>Method 8011:</b>	1,2-Dibromoethane and 1,2-Dibromo-3-chloropropane by Microextraction and Gas Chromatography
<b>Method 8015B:</b>	Nonhalogenated Organics Using GC/FID
<b>Method 8021B:</b>	Aromatic and Halogenated Volatiles by Gas Chromatography Using Photoionization and/or Electrolytic Conductivity Detectors
<b>Method 8031:</b>	Acrylonitrile by Gas Chromatography
<b>Method 8032A:</b>	Acrylamide by Gas Chromatography
<b>Method 8033:</b>	Acetonitrile by Gas Chromatography with Nitrogen-Phosphorus Detection
<b>Method 8041:</b>	Phenols by Gas Chromatography
<b>Method 8061A:</b>	Phthalate Esters by Gas Chromatography with Electron Capture Detection (GC/ECD)
<b>Method 8070A:</b>	Nitrosamines by Gas Chromatography
<b>Method 8081A:</b>	Organochlorine Pesticides by Gas Chromatography
<b>Method 8082:</b>	Polychlorinated Biphenyls (PCBs) by Gas Chromatography
<b>Method 8091:</b>	Nitroaromatics and Cyclic Ketones by Gas Chromatography
<b>Method 8100:</b>	Polynuclear Aromatic Hydrocarbons
<b>Method 8111:</b>	Haloethers by Gas Chromatography
<b>Method 8121:</b>	Chlorinated Hydrocarbons by Gas Chromatography: Capillary Column Technique
<b>Method 8131:</b>	Aniline and Selected Derivatives by Gas Chromatography
<b>Method 8141A:</b>	Organophosphorus Compounds by Gas Chromatography: Capillary Column Technique
<b>Method 8151A:</b>	Chlorinated Herbicides by GC Using Methylation or Pentafluorobenzoylation Derivatization

### 4.3 DETERMINATION OF ORGANIC ANALYTES

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

#### 4.3.2 GAS CHROMATOGRAPHIC/MASS SPECTROMETRIC METHODS

The following methods are included in this section:

- |                      |   |
|----------------------|---|
| <b>Method 8260B:</b> | Volatile Organic Compounds by Gas Chromatography/Mass Spectrometry (GC/MS)  |
| <b>Method 8270C:</b> | Semivolatile Organic Compounds by Gas Chromatography/Mass Spectrometry (GC/MS)  |
| <b>Method 8275A:</b> | Semivolatile Organic Compounds (PAHs and PCBs) in Soils/Sludges and Solid Wastes Using Thermal Extraction/Gas Chromatography/Mass Spectrometry (TE/GC/MS)                       |
| <b>Method 8280A:</b> | The Analysis of Polychlorinated Dibenzo- <i>p</i> -Dioxins and Polychlorinated Dibenzofurans by High Resolution Gas Chromatography/Low Resolution Mass Spectrometry (HRGC/LRMS) |
| <b>Method 8290:</b>  | Polychlorinated Dibenzodioxins (PCDDs) and Polychlorinated Dibenzofurans (PCDFs) by High-Resolution Gas Chromatography/High-Resolution Mass Spectrometry (HRGC/HRMS)            |
| <b>Attachment A:</b> | Procedures for the Collection, Handling, Analysis, and Reporting of Wipe Tests Performed within the Laboratory  |

### 4.3 DETERMINATION OF ORGANIC ANALYTES

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

#### 4.3.3 HIGH PERFORMANCE LIQUID CHROMATOGRAPHIC METHODS

The following methods are included in this section:

<b>Method 8310:</b>	Polynuclear Aromatic Hydrocarbons
<b>Method 8315A:</b>	Determination of Carbonyl Compounds by High Performance Liquid Chromatography (HPLC)
<b>Appendix A:</b>	Recrystallization of 2,4-Dinitrophenylhydrazine (DNPH)
<b>Method 8316:</b>	Acrylamide, Acrylonitrile and Acrolein by High Performance Liquid Chromatography (HPLC)
<b>Method 8318:</b>	N-Methylcarbamates by High Performance Liquid Chromatography (HPLC)
<b>Method 8321A:</b>	Solvent Extractable Nonvolatile Compounds by High Performance Liquid Chromatography/Thermospray/Mass Spectrometry (HPLC/TS/MS) or Ultraviolet (UV) Detection
<b>Method 8325:</b>	Solvent Extractable Nonvolatile Compounds by High Performance Liquid Chromatography/Particle Beam/Mass Spectrometry (HPLC/PB/MS)
<b>Method 8330:</b>	Nitroaromatics and Nitramines by High Performance Liquid Chromatography (HPLC)
<b>Method 8331:</b>	Tetrazene by Reverse Phase High Performance Liquid Chromatography (HPLC)
<b>Method 8332:</b>	Nitroglycerine by High Performance Liquid Chromatography

### 4.3 DETERMINATION OF ORGANIC ANALYTES

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

#### 4.3.4 INFRARED METHODS

The following methods are included in this section:

- |                     |   |
|---------------------|---|
| <b>Method 8410:</b> | Gas Chromatography/Fourier Transform Infrared (GC/FT-IR) Spectrometry for Semivolatile Organics: Capillary Column |
| <b>Method 8430:</b> | Analysis of Bis(2-chloroethyl) Ether and Hydrolysis Products by Direct Aqueous Injection GC/FT-IR                 |
| <b>Method 8440:</b> | Total Recoverable Petroleum Hydrocarbons by Infrared Spectrophotometry  |

#### 4.3 DETERMINATION OF ORGANIC ANALYTES

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

##### 4.3.5 MISCELLANEOUS SPECTROMETRIC METHODS

The following method is included in this section:

**Method 8520:** Continuous Measurement of Formaldehyde in Ambient Air

#### 4.4 IMMUNOASSAY METHODS

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

The following methods are included in this section:

<b>Method 4000:</b>	Immunoassay
<b>Method 4010A:</b>	Screening for Pentachlorophenol by Immunoassay
<b>Method 4015:</b>	Screening for 2,4-Dichlorophenoxyacetic Acid by Immunoassay
<b>Method 4020:</b>	Screening for Polychlorinated Biphenyls by Immunoassay
<b>Method 4030:</b>	Soil Screening for Petroleum Hydrocarbons by Immunoassay
<b>Method 4035:</b>	Soil Screening for Polynuclear Aromatic Hydrocarbons by Immunoassay
<b>Method 4040:</b>	Soil Screening for Toxaphene by Immunoassay
<b>Method 4041:</b>	Soil Screening for Chlordane by Immunoassay
<b>Method 4042:</b>	Soil Screening for DDT by Immunoassay
<b>Method 4050:</b>	TNT Explosives in Soil by Immunoassay
<b>Method 4051:</b>	Hexahydro-1,3,5-trinitro-1,3,5-triazine (RDX) in Soil by Immunoassay

#### 4.5 MISCELLANEOUS SCREENING METHODS

Prior to employing the methods in this chapter, analysts are advised to consult the disclaimer statement at the front of this manual and the information in Chapter Two for guidance on the allowed flexibility in the choice of apparatus, reagents, and supplies. In addition, unless specified in a regulation, the use of SW-846 methods is not mandatory in response to Federal testing requirements. The information contained in each procedure is provided by EPA as guidance to be used by the analyst and the regulated community in making judgements necessary to meet the data quality objectives or needs for the intended use of the data.

The following methods are included in this section:

<b>Method 3810:</b>	Headspace
<b>Method 3820:</b>	Hexadecane Extraction and Screening of Purgeable Organics
<b>Method 8515:</b>	Colorimetric Screening Method for Trinitrotoluene (TNT) in Soil
<b>Method 9078:</b>	Screening Test Method for Polychlorinated Biphenyls in Soil
<b>Method 9079:</b>	Screening Test Method for Polychlorinated Biphenyls in Transformer Oil